



KOBE Range Hoods
"So Quiet...You Won't Believe It's On!"

INX2630SQB-700-2 Parts Location and Replacement

*This basic guide is to show the parts location of the INX2630SQB-700-2 and how to remove or install certain parts.
To see more detailed guidelines, please visit: [Kobe Service and Repair](#)*

For model: INX2630SQB-700-2

Overall Snapshot of INX2630SQB-700-2



1. Blower System ([Manual](#) Part #10 – See “Parts List” page on manual)
2. Controls Unit ([Manual](#) Part #16 – See “Parts List” page on manual)
3. LED Light (3W) ([Manual](#) Part #18 – See “Parts List” page on manual)

Removing the Electric Component Support

Warning: Loosen the screw first with a hand tool screw driver.




Figure 1




Figure 2



Figure 3



4. Electric Component Support ([Manual](#) Part #5 – See “Parts List” page on manual)



KOBE Range Hoods

"So Quiet...You Won't Believe It's On!"

Accessing the Capacitor and Processor Board



5. Capacitor ([Manual](#) Part #7 – See “Parts List” page on manual)
6. Processor Board ([Manual](#) Part #6 – See “Parts List” page on manual)



KOBE Range Hoods

"So Quiet...You Won't Believe It's On!"

Removing the Control Unit




Figure 1



Figure 2



Figure 3



Figure 4

7. Light Panel Support ([Manual](#) Part #17 – See “Parts List” page on manual)

Accessing the LED Light

Warning: For the process above, loosen the screw first with a hand tool screw driver.



For a more detailed guideline, visit:
[How to Replace LED Lights](#)



KOBE Range Hoods

"So Quiet...You Won't Believe It's On!"

Removing the Blower System

Warning:

1. Loosen the screw first with a hand tool screw driver.
2. Place a support or hold the blower before removing it.




Figure 1




Figure 2




Figure 3



Figure 4




Figure 5

1. Blower System ([Manual](#) Part #10 – See “Parts List” page on manual)