



## KOBE Range Hoods


*"So Quiet...You Won't Believe It's On!"*

### ISX21 SQB-1 Parts Location and Replacement

*This basic guide is to show the parts location of the ISX21 SQB-1 and how to remove or install certain parts.  
To see more detailed guidelines, please visit: [Kobe Service and Repair](#)*

*For island models: ISX2130SQB-1, ISX2136SQB-1, ISX2142SQB-1*

#### Overall Snapshot of ISX21 SQB-1



1. Control Switch ([Manual](#) Part #3 – See “Parts List” page on manual)
2. LED Light (3W) ([Manual](#) Part #2 – See “Parts List” page on manual)



## KOBE Range Hoods

*"So Quiet...You Won't Believe It's On!"*

### Accessing the Capacitor and LED Light Driver




Figure 1




Figure 2

- 3. Capacitor ([Manual](#) Part #5 – See “Parts List” page on manual)
- 4. LED Light Driver ([Manual](#) Part #4 – See “Parts List” page on manual)

### Accessing the LED Light



*For a more detailed guideline, visit:*  
[How to Replace LED Lights](#)



# KOBE Range Hoods

*“So Quiet...You Won't Believe It's On!”*

## Removing the Control Switch

*Warning: Loosen the screw first with a hand tool screw driver.*



Figure 1



Figure 2




Figure 3



Figure 4



Figure 5




Figure 6

5. Capacitor Support ([Manual](#) Part #6 – See “Parts List” page on manual)



# KOBE Range Hoods

*"So Quiet...You Won't Believe It's On!"*

## Removing the Blower System

**Warning:**

1. Loosen the screw first with a hand tool screw driver.
2. Place a support or hold the blower before removing it.

Pull the wire down so the blower can be removed.




Figure 1




Figure 2



Figure 3




Figure 4



Figure 5




Figure 5

6. Blower System ([Manual](#) Part #10 – See “Parts List” page on manual)