



KOBE Range Hoods

“So Quiet...You Won’t Believe It’s On!”

RAX21 SQB-1 Parts Location and Replacement

This basic guide is to show the parts location of the RAX21 SQB-1 and how to remove or install certain parts.
To see more detailed guidelines, please visit: [Kobe Service and Repair](#)

For under cabinet models: RAX2130SQB-1, RAX2136SQB-1, RAX2142SQB-1
For wall mount models: RAX2130SQB-WM-1, RAX2136SQB-WM-1, RAX2142SQB-WM-1

Overall Snapshot of RAX21 SQB-1



1. Blower System ([Manual](#) Part #7 – See “Parts List” page on manual)
2. Control Switch ([Manual](#) Part #6 – See “Parts List” page on manual)
3. LED Light (3W) ([Manual](#) Part #5 – See “Parts List” page on manual)



KOBE Range Hoods

“So Quiet...You Won’t Believe It’s On!”

Removing the LED Light Support

Warning: Loosen the screw first with a hand tool screw driver.



Figure 1



Figure 2



Figure 3

4. LED Light Support ([Manual](#) Part #4 – See “Parts List” page on manual)



KOBE Range Hoods

“So Quiet...You Won’t Believe It’s On!”

Accessing the Capacitor and LED Driver



Figure 1




Figure 2




Figure 3

Warning: For the process above, loosen the screw first with a hand tool screw driver.

- 5. Capacitor ([Manual](#) Part #2 – See “Parts List” page on manual)
- 6. LED Light Driver ([Manual](#) Part #3 – See “Parts List” page on manual)

Accessing the LED Light



For a more detailed guideline, visit: [How to Replace LED Lights](#)



KOBE Range Hoods

“So Quiet...You Won't Believe It's On!”

Removing the Control Switch

Warning: Loosen the screw first with a hand tool screw driver.




Figure 1




Figure 2



Figure 3



Figure 4



Figure 5




Figure 6

2. Control Switch ([Manual](#) Part #6 – See “Parts List” page on manual)



KOBE Range Hoods

“So Quiet...You Won’t Believe It’s On!”

Removing the Blower System

Warning:

1. Loosen the screw first with a hand tool screw driver.
2. Place a support or hold the blower before removing it.




Figure 1



Figure 2



Figure 3

1. Blower System ([Manual](#) Part #7 – See “Parts List” page on manual)