




KOBE Range Hoods
“So Quiet ... You Won’t Believe It’s On!”

INX28 SQ-700-1 Parts Location and Replacement

*This basic guide is to show the parts location of the INX28 SQ-700-1 and how to remove or install certain parts.
To see more detailed guidelines, please visit: [KOBE Service and Repair](#)*

*For model: INX2830SQB-700-1
INX2830SQH-700-1*

Overall Snapshot of INX28 SQ-700-1



1. Blower System ([Manual](#) Part #3 – See “Parts List” page on manual)
2. Control Switch ([Manual](#) Part #7 – See “Parts List” page on manual)
3. LED Light (3W) ([Manual](#) Part #8 – See “Parts List” page on manual)
4. Electronic Component Box ([Manual](#) Part #4 – See “Parts List” page on manual)



KOBE Range Hoods

"So Quiet ... You Won't Believe It's On!"

Accessing the Capacitor and LED Driver




Figure 1




Figure 2

5. Capacitor ([Manual](#) Part #6 – See “Parts List” page on manual)
6. LED Driver ([Manual](#) Part #5 – See “Parts List” page on manual)

Removing the Blower System




Figure 1




Figure 2

1. Blower System ([Manual](#) Part #3 – See “Parts List” page on manual)



KOBE Range Hoods

"So Quiet ... You Won't Believe It's On!"

Removing the Bottom Casing



Figure 1



Figure 2



Figure 3




Figure 4



KOBE Range Hoods

"So Quiet ... You Won't Believe It's On!"

Removing the Control Switch




Figure 1





Figure 2

Accessing the LED Light



2. Control Switch ([Manual](#) Part #7 – See “Parts List” page on manual)
3. LED Light (3W) ([Manual](#) Part #8 – See “Parts List” page on manual)