

KOBE Range Hoods

"So Quiet ... You Won't Believe It's On!"

IN28 SQB-XX Parts Location and Replacement

This basic guide is to show the parts location of the IN28 SQB-XX and how to remove or install certain parts.

To see more detailed guidelines, please visit: KOBE Service and Repair

For 30" model: IN2830SQB-XX

Overall Snapshot of IN28 SQB-XX



- 1. Blower System (Manual Part #3 See "Parts List" page on manual)
- 2. Control Switch (Manual Part #7 See "Parts List" page on manual)
- 3. LED Light (6W) (Manual Part #8 See "Parts List" page on manual)



KOBE Range Hoods "So Quiet ... You Won't Believe It's On!"

Removing the Bottom Casing





Figure 2 Figure 1





Figure 3 Figure 4



KOBE Range Hoods

"So Quiet ... You Won't Believe It's On!"

Accessing the Capacitor and LED Driver






Figure 1

Figure 2

- 4. Capacitor (Manual Part #6 See "Parts List" page on manual)
- 5. LED Driver (Manual Part #5 See "Parts List" page on manual)

Removing the Blower System






Figure 1

Figure 2

1. Blower System (Manual Part #3 – See "Parts List" page on manual)



KOBE Range Hoods"So Quiet ... You Won't Believe It's On!"

Removing the Control Switch






Figure 2 Figure 1

Accessing LED Light




Figure 1

- 2. Control Switch (Manual Part #7 See "Parts List" page on manual)
- 3. LED Light (6W) (Manual Part #8 See "Parts List" page on manual)